

Here's Why Fill n' Finish For Pore Filling Is Superior!

- No Naptha odor! Doesn't smell like the currently used brown product
- Very easy to work with. Can be applied with a squeegee
- Can go to the booth and be sprayed over in 30 minutes. No more 24 hour wait time to spray!
- Stays flexible and breathes with the wood
- Works with all finishes and woods!

Instructions

Using GluBoost for pore filling before nitro

Sand wood to 200-220 grit

Wipe clean

Apply Fill n' Finish and spread and work in with shop towel, rag, foam brush or plastic card. note: can be used with MasterTint added for effect/ enhancement if desired.

Important! Wipe wet Fill n' Finish "cross grain" with a rag. note: when wiping always go "cross grain"

Spray light burst of GluDry

Important! Sand with 220 grit so that remaining Fill n' Finish in driven into wood.

Wipe area clean with a shop towel or rag.

Steps 8-12 optional but highly recommended for optimal results.

Add a second coat of Fill n' Finish

Wipe area with shop towel or rag

Spray with GluDry and let dry for 10-30 minutes depending on wood.

Sand with 220 grit

Wipe area clean with shop towel or rag

Ready for lacquer

See it work

www.youtube.com/watch?v=jZA6hyxwEJM&t=7s **Questions?**

Call us at 201.331.3730, option 1 and ask for Rick

