

MasterTint



MasterTint White With Another Color

1. Place some MasterGlu or Fill n' Finish on your GluBoost Mixing Palette.
2. Using a GluBoost Spatula, add your desired color to the product slowly in a mixing pattern.
3. Always break up clumps as you go along.
4. Add more color as needed to match the desired color
5. Add a second color if the desired shade requires further mix/matching.
6. If the product thickens, add more MasterGlu or Fill n' Finish and continue to mix until ready to apply.

**Note: When using white additive with another color, always add that color first, then the white.*

**If the white won't go into the color as instructed above, use the below White Color Alone method below and then add the residual dry white powder to the color.*

MasterTint



Using White Color Alone

1. In a Mix Cup, add the white to a small amount of acetone and mix until the acetone dissolves.
2. Add the residual white powder to the MasterGlu or Fill n' Finish.

Alternative Method

1. Place some MasterGlu or Fill n' Finish on your GluBoost Mixing Palette.
2. Using a GluBoost Spatula, add the white to a small amount of acetone to get to the desired opaqueness.
3. Add this mixture to your MasterGlu or Fill n' Finish.
4. If the product begins to thicken, just add more MasterGlu or Fill n' Finish.

MasterTint Best Use Tips

MasterTint mixes into Gluboost adhesives and finishes much more effectively in low humidity conditions. 45 percent humidity or less is best to prevent any clumping. Be sure to crush any powder tint that may have clumped/coagulated before adding it to the adhesive or finish.



www.gluboost.com

Sales/Technical Info Contact: 201.331.3730

Email: info@gluboost.com

Gear Up Products, LLC

652 Primrose Lane River Vale, NJ 07675

GluBoost®, MasterGlu™

MasterTint™ and Fill n' Finish™
are Trademarks of Gear Up Products, LLC

Copyright © 2017 Gear Up Products, LLC

GLU+BOOST

GLUBOOST PRODUCT APPLICATION INSTRUCTIONS



GluBoost

For Build Ups Using CA Adhesive Only!

1. Apply your favorite glue.
2. Spray GluBoost from 10-12" away from the area. GluBoost will bond glue instantly.
3. Apply another layer of your favorite glue.
4. Repeat steps 1-3 until your fill is just how you want it.

For Attaching Parts Together

1. Apply your favorite glue to one of your parts.
2. Spray the other part with GluBoost.
3. Put the parts together and voila!

GluBoost Best Use Tips

When top coating or finishing make sure to wipe GluBoost Spray off each time between coats and before reapplying adhesive or finisher



Fill n' Finish Thin

Use with GluBoost accelerator for super fast and clear finish and repair work.

For flexible top coats, on the spot drop fills, and effective repair of dings and dents:

1. Prepare area as you normally would.
2. Apply Fill n' Finish Thin.
3. Spray with GluBoost.
4. Use Fill n' Finish Pro Formula to fill deeper ding if needed.
5. Spray with GluBoost.
6. Wait (See Take Note! Below for drying time information.)
7. Light polish using micro mesh and or a polishing compound if desired.
8. Fnf Thin can be used for your final top coat if desired.



Fill n' Finish Pro Formula

Handle your drop fills quickly and easily with these simple instructions:

1. Clean fill area.
2. Spray drop area with GluBoost.
3. Add some Fill n' Finish Thin at the bottom of the fill area.
4. Lightly spray GluBoost in short spurts from 8" away and wait at least a couple of minutes before proceeding*.
5. Add a small amount of Fill n' Finish Pro Formula.
6. Spray GluBoost and wait a couple of minutes before proceeding. (See Take Note! Below for drying time information.)
7. Continue steps 4 and 5 until near level. Fnf Thin can be used for your final top coat if desired.

Take Note!

DRYING TIMES WILL VARY

Always allow Fill n' Finish time to dry before working or adding more product. It is always best to drop fill in small amounts at a time when using Fill n' Finish. A short spray of GluBoost before drop filling with Fill n' Finish is recommended.

When using Fill n' Finish with Nitro, always spray GluBoost first before drop filling and again after filling. But in general, always wait as long as possible for Fill n' Finish to dry before working or building up your fill.

Fill n' Finish Best Use Tips

1. DO NOT REFRIGERATE OPEN BOTTLES. Doing so will create condensation that will accelerate product curing inside the bottle.
2. Remember to never touch the tip of Fill n' Finish to any area already sprayed with GluBoost.
3. Whip tips and extender tips are available, and are to be used to adjust flow and specificity for your particular job.



MasterGlu UltraThin

MasterGlu UltraThin Instructions

1. Prepare surface as you normally would
2. Apply MasterGlu UltraThin
3. Spray with GluBoost
4. Repeat application if needed.

Remember to never touch the tip of MasterGlu ULTRATHIN to any area already sprayed with GluBoost.

For Attaching Parts Together

1. Apply MasterGlu UltraThin to one of your parts
2. Spray the other part with GluBoost
3. Put the parts together and voila!

Note: GluBoost works super fast!!! Once GluBoost is applied, you will only have two seconds for adjustment before it sets, so be sure you are accurate when connecting the two parts.



MasterGlu Thin

MasterGlu Thin Instructions

1. Prepare surface
2. Apply MasterGlu Thin
3. Spray with GluBoost
4. Repeat application if needed.

Remember: Never touch the tip of MasterGlu Thin to any area already sprayed with GluBoost.

For Attaching Parts Together

1. Apply MasterGlu Thin to one of your parts
2. Spray the other part with GluBoost
3. Put the parts together and voila!

Note: GluBoost works super fast!!! Once GluBoost is applied, you will only have two seconds for adjustment before it sets, so be sure you are accurate when connecting the two parts.

MasterGlu Best Use Tips

DO NOT REFRIGERATE OPEN BOTTLES. Doing so will create condensation that will accelerate product curing inside the bottle.

MasterTint



GENERAL MASTERTINT INSTRUCTIONS

1. Place some MasterGlu CA or Fill n' Finish onto your mixing palette.
2. Add your desired MasterTint color(s) as needed to mix and match to your finish.
3. Apply the mixed product to the work area.
4. Spray with GluBoost. Repeat steps 3 and 4 to build up.
5. Add clear product as your top coat. Spray with GluBoost and work the finish to the desired sheen.

NOTE: If the product thickens, simply add more MasterGlu or Fill n' Finish and continue to mix until ready to apply.

Master Tint is concentrated, and adding too much can affect drying. Multiple sprays of GluBoost may be needed for complete drying.

Hint: If repairing a deep ding, prefill the ding with clear Fill n' Finish or MasterGlu to build up. Then mix MasterTint into some Fill n' Finish or MasterGlu and apply near the top of the build up. Remember to always complete your fills with clear Fill n' Finish over the color matched product before sanding or polishing!

Important: If Master Tint has clumped, pulverize to powder before use.