



## Instructions

Using GluBoost for  
pore filling before nitro



Sand wood to 200-220 grit

Wipe clean

Apply Fill n' Finish and spread and work in with shop towel, rag, foam brush or plastic card. note: can be used with MasterTint added for effect/ enhancement if desired.

**Important!** Wipe wet Fill n' Finish "cross grain" with a rag. note: when wiping always go "cross grain"

Spray light burst of GluDry

**Important!** Sand with 220 grit so that remaining Fill n' Finish is driven into wood.

Wipe area clean with a shop towel or rag.

**Steps 8-12 optional but highly recommended for optimal results.**

Add a second coat of Fill n' Finish

Wipe area with shop towel or rag

Spray with GluDry and let dry for 10-30 minutes depending on wood.

Sand with 220 grit

Wipe area clean with shop towel or rag

Ready for lacquer

### See it work

<https://www.youtube.com/watch?v=jZA6hyxwEJM&t=7s>

**Questions?** Call us at 201.331.3730, option 1 and ask for Rick